

По вопросам продаж и поддержки обращайтесь:

| | | |
|-----------------------------|---------------------------------|--------------------------------|
| Архангельск (8182)63-90-72 | Краснодар (861)203-40-90 | Санкт-Петербург (812)309-46-40 |
| Астана (7172)727-132 | Красноярск (391)204-63-61 | Саратов (845)249-38-78 |
| Астрахань (8512)99-46-04 | Курск (4712)77-13-04 | Севастополь (8692)22-31-93 |
| Барнаул (3852)73-04-60 | Липецк (4742)52-20-81 | Симферополь (3652)67-13-56 |
| Белгород (4722)40-23-64 | Магнитогорск (3519)55-03-13 | Смоленск (4812)29-41-54 |
| Брянск (4832)59-03-52 | Москва (495)268-04-70 | Сочи (862)225-72-31 |
| Владивосток (423)249-28-31 | Мурманск (8152)59-64-93 | Ставрополь (8652)20-65-13 |
| Волгоград (844)278-03-48 | Набережные Челны (8552)20-53-41 | Сургут (3462)77-98-35 |
| Вологда (8172)26-41-59 | Нижний Новгород (831)429-08-12 | Тверь (4822)63-31-35 |
| Воронеж (473)204-51-73 | Новокузнецк (3843)20-46-81 | Томск (3822)98-41-53 |
| Екатеринбург (343)384-55-89 | Новосибирск (383)227-86-73 | Тула (4872)74-02-29 |
| Иваново (4932)77-34-06 | Омск (3812)21-46-40 | Тюмень (3452)66-21-18 |
| Ижевск (3412)26-03-58 | Орел (4862)44-53-42 | Ульяновск (8422)24-23-59 |
| Казань (843)206-01-48 | Оренбург (3532)37-68-04 | Уфа (347)229-48-12 |
| Калининград (4012)72-03-81 | Пенза (8412)22-31-16 | Хабаровск (4212)92-98-04 |
| Калуга (4842)92-23-67 | Пермь (342)205-81-47 | Челябинск (351)202-03-61 |
| Кемерово (3842)65-04-62 | Ростов-на-Дону (863)308-18-15 | Череповец (8202)49-02-64 |
| Киров (8332)68-02-04 | Рязань (4912)46-61-64 | Ярославль (4852)69-52-93 |
| | Самара (846)206-03-16 | |

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru

Система iModView PIXSYS. Техническое описание

TD700 with monitoring software up to 30 zones



iModViewCE software has been developed to monitor and control **Pixsys controllers** via RS485 interface and is only available pre-installed on HMI WinCE model TD700-AD.

Via ModbusRTU connection it is possible to monitor up to 30 zones.

The software also allows to instantly set the same setpoint value for all zones or to control the setpoint value of the selected individual zone .

A specific function enables recording of process and setpoint values in a .csv file and export via USB key or Ethernet connection. It is possible to see the process and setpoint trend for each individual zone also as graph.

The software can display texts in 5 languages (English, Italian, German, French and Spanish).

The **HMI panel TD700 and the controllers** communicate via Modbus Rtu protocol on RS485 serial with BaudRate 19200 bit/s (Pixsys default setting) and format 8,N,1.

Ordering codes

2100.20.010

Runtime iModViewCE30 zone (TD700-AD)

2100.20.016

Runtime iModviewX86 60 zone (TD900-A)

Software features

Trend

Single trend for each zone with historical of 5 last hours

Setpoint

Possibility of change single setpoint or global setpoint

Alarms

Alarm active for each zone, historical alarms (100 records).

Export file

By USB key or by Ethernet connection.

Languages

Italian, English, German, French and Spanish.

По вопросам продаж и поддержки обращайтесь:

| | | |
|-----------------------------|---------------------------------|--------------------------------|
| Архангельск (8182)63-90-72 | Краснодар (861)203-40-90 | Санкт-Петербург (812)309-46-40 |
| Астана (7172)727-132 | Красноярск (391)204-63-61 | Саратов (845)249-38-78 |
| Астрахань (8512)99-46-04 | Курск (4712)77-13-04 | Севастополь (8692)22-31-93 |
| Барнаул (3852)73-04-60 | Липецк (4742)52-20-81 | Симферополь (3652)67-13-56 |
| Белгород (4722)40-23-64 | Магнитогорск (3519)55-03-13 | Смоленск (4812)29-41-54 |
| Брянск (4832)59-03-52 | Москва (495)268-04-70 | Сочи (862)225-72-31 |
| Владивосток (423)249-28-31 | Мурманск (8152)59-64-93 | Ставрополь (8652)20-65-13 |
| Волгоград (844)278-03-48 | Набережные Челны (8552)20-53-41 | Сургут (3462)77-98-35 |
| Вологда (8172)26-41-59 | Нижний Новгород (831)429-08-12 | Тверь (4822)63-31-35 |
| Воронеж (473)204-51-73 | Новокузнецк (3843)20-46-81 | Томск (3822)98-41-53 |
| Екатеринбург (343)384-55-89 | Новосибирск (383)227-86-73 | Тула (4872)74-02-29 |
| Иваново (4932)77-34-06 | Омск (3812)21-46-40 | Тюмень (3452)66-21-18 |
| Ижевск (3412)26-03-58 | Орел (4862)44-53-42 | Ульяновск (8422)24-23-59 |
| Казань (843)206-01-48 | Оренбург (3532)37-68-04 | Уфа (347)229-48-12 |
| Калининград (4012)72-03-81 | Пенза (8412)22-31-16 | Хабаровск (4212)92-98-04 |
| Калуга (4842)92-23-67 | Пермь (342)205-81-47 | Челябинск (351)202-03-61 |
| Кемерово (3842)65-04-62 | Ростов-на-Дону (863)308-18-15 | Череповец (8202)49-02-64 |
| Киров (8332)68-02-04 | Рязань (4912)46-61-64 | Ярославль (4852)69-52-93 |
| | Самара (846)206-03-16 | |

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru