

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru

Преобразователи тока PIXSYS. Техническое описание

Signal converter from Current transformer to 4...20mA / RS485



The 2000.35.013 is a direct and alternating current transformer, galvanically isolated from the measuring circuit. The device is functionally and aesthetically similar to a standard active TA, but is able to measure the TRMS direct and alternating component. The transformer is powered in loop with current 4-20mA and thus does not require a direct power supply. It is the first Hall loop-powered transformer with a precision of 0.5% on the market.

On the version with serial output RS485 Modbus (2000.35.014) and analogue output 0-10V, the span and zero can be freely configured and a Modbus address assigned; it is easy to configure using the library in the development tools of Pixsys HMIs.

Ordering codes

2000.35.013

Current transformer >4...20mA Loop Powered

2000.35.014

Current transformer >RS485 Modbus /slave + 0...10Volt

Main features

Dimensions

46,1 x 63 x 26,4 mm (terminal block excluded)

Power supply

Loop-powered (2 wires) operating range 11-30 Vdc 12...35Vdc on version with RS485

Connection

screw terminal 5,08mm

Fixing

DIN-rail (horizontal/vertical)

Operating conditions

Temperature -40+85 °C, humidity 10..90 uR% (non condensing)

Material

Gray PBT, epoxy resin filling

Weight

Approx. 72 g

Dip-switch

2 / 8 poles

Conformity standards

CE, EN 61000-6-4, EN 61000-6-2, EN 61010-1

Technical data

Measure type

TRMS

Resolution and accuracy

12 Bit - 0,5% full scale

Capacity

50 Arms or 25 Arms selectable by Dip-Switch, bipolar (+/-50A dc or +/-25A dc)

Output

4...20mA or 0...10Volt + RS485

Passband -3dB

DC or 20...2000Hz

Response speed

1000 ms

Isolation

3 Kv on bare cable

Overload

2 kA impulsive, 300 continuous

Crest factor

2

Hysteresis on measured value

0,15% full scale

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru