

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru

Модули расширения PL300 PIXSYS. Техническое описание

PL300

I/O Acquisition/actuation module for PLC/HMI



Acquisition and actuation module, usable as extension for operator panels with integrated logic (ATR313, TD329, TD240) or SCADA software. In a standard container DIN43880 9 modules for rail mount, there are 4 controllers with universal input and a wide range of outputs, both analogue for transmission and control and relay for actuation on systems with alternating current. On a single Plug type connector and on extractable terminals there is an RS232 port and an RS482 port, both with Modbus RTU - Slave protocol.

To simplify the logic on the network nodes, the device can retrieve pre-programmed functions for servo-valve control and management of alarms or input analogics, as well as the clock function with back-up.

Ordering codes

PL300-10AD

4 An. Inp. + 6 Digital + 12 relays + 2 outputs V/mA

PL300-30AD

4 An. Inp. + 6 Digital + 4 SSR-12Volt + 8 relays + 2 outputs V/mA

Main features

Box

Standard DIN43880 160 x 90 x 58 (H) mm with DIN RAIL mounting fittings EN50022

Power supply

12...24Vac/Vdc $\pm 15\%$ 50/60 Hz

Consumption

10W

Operating conditions

Temperature 0-45 °C, humidity 35..95 uR% (non condensing)

Material

Noryl V0

Weight

Approx. 460 gr

Sealing

IP20 Box

Inputs

Analogue

4 Selectable for TC, K, J, S, R, T, E, PT100,PT1000, Ni100, 0/4..20 mA, 0/1..10 V, 0...50mV

Sampling time

250 ms

Resolution

14 bit

Digital

6 PNP inputs

Outputs

Digital

12 Relays 5A resistive charge

Analogue

2 selectable by Jumper as 0...10Volt or 4...20mA for retransmission or command

Communication ports

1 serial RS232 on plug + 1 serial RS485 on Plug or on extractable terminal (or Current-loop 20mA)

Software features

HMI - Operator interface

ATR313/ATR640 for kilns or environmental chambers, TD240 / TD320 / SCADA for other industrial applications for supervisory/monitoring functions

Communication protocol

Modbus RTU Slave

Analogue inputs control algorithms

ON - OFF with hysteresis, P., P.I., P.I.D., P.D. time-proportioned

Clock

Real-Time clock, Back-up battery

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru