

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru

Преобразователи температуры DIN PIXSYS. Техническое описание

DIN rail mounted signal converter - RFid / NFC



The signal transmitter from DIN rail converts a signal received through probes PT100, Ni100 (with 2-, 3- and 4-wire connections), thermocouples or process signals (0/4..20mA, 0..10V) into a normalised current signal 4..20 mA (2-wire power loop). The characteristics of these converters ensure high precision on the reading scale with 16 bit conversion and the possibility to rescale the analogue output 4..20 mA according to the input set. The RTD/TC input is galvanically isolated at 2500 V from the analogue output, which ensure safer cables in environment where they may be disturbed or in cases where there different voltages in the same system.

Ordering codes

2000.35.016

RTD (PT100/NI100)+ TC (K-S-R-J-T-N-B-E) to 4..20 mA Loop Powered - isolated version

2000.35.017

0..20 mA / 4..20 mA / 0..10V / resistance to 4..20 mA loop powered - isolated version

Main features

Box

DIN43880, Din rail mounted 1 module

Current output

4..20 mA Loop Power (2 wires), operating range 6-32 V DC

Connection

Screw pins

Operating temperature

-40+85 °C, humidity 30..90 RH% (non condensing)

Material

Box: polycarbonate V0; Front panel: silicon V0

Weight

Approx. 30 g

Set-up

Programmable by RFid (NFC)

Technical data

Selectable analogue input

PT100 (2/3/4 wires), Ni100, TC K-S-R-J-T-N-B-E, 0..20 mA, 4..20 mA, 0..10V, 0..4000Ω

Digital Input

Button for calibration functions

Isolation

Galvanic isolation input/output

Output resolution

1μA

Failure output

selectable 21,5 mA or 3,8 mA

Current output protection

30 mA approx.

Rejection

50-60 Hz

Sampling/response time

300ms / approx. 600 ms

Cable resistance

Max 20Ω

Temperature coefficient

< 100 ppm

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru