

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru

Твердотельные реле SAL/SU/SUL PIXSYS. Техническое описание

32A current

Zero-Crossing solid state relays are devices that activate when voltage in the output circuit passes near 0 and deactivate when the current is 0. They are particularly useful in applications with resistive load.



The SAL series features an integrated dissipator with a DIN-bar mount, and is notable for its minimal size.

Ordering codes series SAL (screw terminals)

2200.00.077

SSR 32A / 24-600 V AC / Ctrl 3,5-32 V DC led and heatsink

2200.00.078

SSR 35A / 24-600 V AC / Ctrl 3,5-32 V DC led

2200.00.079

SSR 50A / 24-600 V AC / Ctrl 3,5-32 V DC led

Ordering codes series SU/SUL (terminal block for DRR450)

2200.00.085

SSR 30A/ 24-400 V AC / Ctrl 3,5-32 V DC Led and Heatsink

2200.00.083

SSR 35A / 24-600 V AC / Ctrl 3,5-32 V DC

2200.00.079

SSR 50A / 24-600 V AC / Ctrl 3,5-32 V DC

2200.00.084

SSR 75A / 24-600 V AC / Ctrl 3,5-32 V DC

2200.00.100

Heatsink for 32A with DIN adapter

2200.00.099

Heatsink for 50A with DIN adapter

Ordering codes NO zero crossing (ATR227 / DRR227)

2200.00.114

SSR 50A / 24-510 V AC / Ctrl 3,5-32 V DC Led and Heatsink

Main features

Technology

Zero-Cross with low zero-crossing level, for applications with resistive charge

Control voltage

8...30 V DC to 3,5...30 V DC

Output voltage

12...280 V AC (25A) to 24...600 V AC(125A)

Signaling Led

Control status LED

Protection

Against short-circuit on output

Sealing

Protection covers IP20 on screw connection

Easy-up code

Code 4400 for the whole range

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru **Веб-сайт:** www.pixsys.nt-rt.ru