

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru

Таймеры TCT201 PIXSYS. Техническое описание

Timer – Counter – Tachometer 48x48 TCT201

Timer - Counter - Tachometer, programmable PNP/NPN inputs, multi-voltage power supply.



The TCT201 series is available in a range of configurations: Timer, Counter, Tachometer/Frequency counter.

TCT201-1ABC with 5 operating modes: Timer-ON, Timer-OFF, Pause-Work, Oscillator, PWM (proportional time output), all with settings independent of the ON-OFF times.

TCT201-2ABC, can be configured as single/double counter, incremental and decremental counter with the option of setting an external potentiometer.

User friendly, multimedia support and traceability

For the entire range of Pixsys products we provide technical support for installation, programming and operation via our online forum and via Skype.

The interface of the TIMER TCT201 ensures that the product is easy to use and that the user is also supported by auxiliaries for programming such as MEMORY-CARD or the LABSOFTVIEW programming software.

Programming tutorial videos are available on our youtube channel.

As for the entire range of PIXSYS products, thanks to the QR code the traceability of the product is guaranteed for its entire life cycle; the information and documentation online can be also be

accessed by reading the QR CODE that directs your mobile device to the product's technical specifications and verifies its warranty conditions.

Ordering codes

TCT201-1ABC

Timer - settable in 5 modes

TCT201-2ABC

Counter - incremental, decremental or bi-directional (encoder)

TCT201-3ABC

Tachometer - for Push -Pull /Line-Driver encoders (mono/bi-directional)

Main features

Box

48x48 (front panel) x 107 mm

Power supply

24...230Vac/Vdc $\pm 15\%$ 50/60 Hz

Consumption

3 VA

Display

4 digits 0,4" green + 4 digits 0,3" red + led

Operating conditions

Temperature 0-45 °C, humidity 35..95 RU% (non condensing)

Material

Box: Noryl UL94V1 self-extinguishing; Front panel: PC ABS UL94V0 self-extinguishing

Weight

Approx. 350 g

Quick set-up options

Memory Card with / without battery

Inputs

3 Digital

Selectables as NPN - PNP - TTL, both on high/low/rising edge level

Input I3

Input selection by potentiometer 5/10 KOhm for setting of setpoint value (resolution 1000 points)

Outputs

2 Relays

2 Relays 8 A - 250 Vac resistive charge

Software features

Timer inputs selection

Start, Stop, Hold, Reset, Wait

Ranges

programmable Time basis sec/100, sec/10, sec , min , hours

Counter inputs selections

Up, Down, Lock, Hold

Count frequency

Incremental / Decremental up to 100Khz

Counter functions

Counting frequency visualization on red display for flowmeter function

Data protection

Parameters protected by password

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Краснодар (861)203-40-90	Санкт-Петербург (812)309-46-40
Астана (7172)727-132	Красноярск (391)204-63-61	Саратов (845)249-38-78
Астрахань (8512)99-46-04	Курск (4712)77-13-04	Севастополь (8692)22-31-93
Барнаул (3852)73-04-60	Липецк (4742)52-20-81	Симферополь (3652)67-13-56
Белгород (4722)40-23-64	Магнитогорск (3519)55-03-13	Смоленск (4812)29-41-54
Брянск (4832)59-03-52	Москва (495)268-04-70	Сочи (862)225-72-31
Владивосток (423)249-28-31	Мурманск (8152)59-64-93	Ставрополь (8652)20-65-13
Волгоград (844)278-03-48	Набережные Челны (8552)20-53-41	Сургут (3462)77-98-35
Вологда (8172)26-41-59	Нижний Новгород (831)429-08-12	Тверь (4822)63-31-35
Воронеж (473)204-51-73	Новокузнецк (3843)20-46-81	Томск (3822)98-41-53
Екатеринбург (343)384-55-89	Новосибирск (383)227-86-73	Тула (4872)74-02-29
Иваново (4932)77-34-06	Омск (3812)21-46-40	Тюмень (3452)66-21-18
Ижевск (3412)26-03-58	Орел (4862)44-53-42	Ульяновск (8422)24-23-59
Казань (843)206-01-48	Оренбург (3532)37-68-04	Уфа (347)229-48-12
Калининград (4012)72-03-81	Пенза (8412)22-31-16	Хабаровск (4212)92-98-04
Калуга (4842)92-23-67	Пермь (342)205-81-47	Челябинск (351)202-03-61
Кемерово (3842)65-04-62	Ростов-на-Дону (863)308-18-15	Череповец (8202)49-02-64
Киров (8332)68-02-04	Рязань (4912)46-61-64	Ярославль (4852)69-52-93
	Самара (846)206-03-16	

Единый адрес: psx@nt-rt.ru Веб-сайт: www.pixsys.nt-rt.ru